








# 1 3/4" INSWING / OUTSWING FRENCH DOOR TRANSOMS

1 FRAME 1 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)





<b>Clad MO (mm)</b>	1-8 11/32 (517)	2-1 15/16 (659)	2-7 15/16 (811)	2-9 15/16 (862)	3-1 15/16 (964)	3-7 15/16 (1116)	4-1 1/8 (1248)
<b>Wood MO (mm)</b>	1-10 31/32 (583)	2-4 9/16 (725)	2-10 9/16 (878)	3-0 9/16 (929)	3-4 9/16 (1030)	3-10 9/16 (1183)	4-3 3/4 (1314)
<b>RO (mm)</b>	1-8 27/32 (529)	2-2 7/16 (672)	2-8 7/16 (824)	2-10 7/16 (875)	3-2 7/16 (976)	3-8 7/16 (1129)	4-1 5/8 (1260)
<b>FS (mm)</b>	1-7 27/32 (504)	2-1 7/16 (646)	2-7 7/16 (799)	2-9 7/16 (849)	3-1 7/16 (951)	3-7 7/16 (1103)	4-0 5/8 (1235)
<b>DLO (mm)</b>	0-11 1/2 (292)	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)	3-0 25/32 (934)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)							
	1616	2016	2616	2816	3016	3616	4016
	1620	2020	2620	2820	3020	3620	4020
	1626	2026	2626	2826	3026	3626	4026

<b>Clad MO (mm)</b>	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
<b>Wood MO (mm)</b>	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
<b>RO (mm)</b>	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
<b>FS (mm)</b>	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
<b>DLO (mm)</b>	4-0 25/32 (1239)	4-4 25/32 (1341)	5-0 25/32 (1544)	6-0 25/32 (1849)






  

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)				
	5016	5416	6016	7016
	5020	5420	6020	7020
	5026	5426	6026	7026

1 FRAME 2 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	4-1 1/8 (1248)	5-1 1/8 (1553)	5-5 1/8 (1654)	6-1 1/8 (1857)	7-1 1/8 (2162)
<b>Wood MO (mm)</b>	4-3 3/4 (1314)	5-3 3/4 (1619)	5-7 3/4 (1721)	6-3 3/4 (1924)	7-3 3/4 (2229)
<b>RO (mm)</b>	4-1 5/8 (1260)	5-1 5/8 (1565)	5-5 5/8 (1667)	6-1 5/8 (1870)	7-1 5/8 (2175)
<b>FS (mm)</b>	4-0 5/8 (1235)	5-0 5/8 (1540)	5-4 5/8 (1641)	6-0 5/8 (1845)	7-0 5/8 (2149)
<b>DLO (mm)</b>	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)					
	4016	5016	5416	6016	7016
	4020	5020	5420	6020	7020
	4026	5026	5426	6026	7026






2-0 and 2-6 Heights:		
	2-0 Height	2-6 Height
Clad MO (mm)	2-0 1/4 (616)	2-6 1/4 (768)
Wood MO (mm)	2-2 1/4 (667)	2-8 1/4 (819)
RO (mm)	2-0 1/2 (622)	2-6 1/2 (775)
FS (mm)	2-0 (610)	2-6 (762)
DLO (mm)	1-3 5/16 (389)	1-9 5/16 (541)

Ultimate Inswing French Door Transoms: UIFDTR  
 Ultimate Outswing French Door Transoms: UOFDTR  
 Ultimate Wood Inswing French Door Transoms: UWIFDTR  
 Ultimate Wood Outswing French Door Transoms: UWOFDTR

# 1 3/4" INSWING / OUTSWING FRENCH DOOR TRANSOMS






1 FRAME 3 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	6-0 5/16 (1837)	7-6 5/16 (2294)	8-0 5/16 (2446)	9-0 5/16 (2751)	10-6 5/16 (3208)
<b>Wood MO (mm)</b>	6-2 15/16 (1903)	7-8 15/16 (2361)	8-2 15/16 (2513)	9-2 15/16 (2818)	10-8 15/16 (3275)
<b>RO (mm)</b>	6-0 13/16 (1849)	7-6 13/16 (2307)	8-0 13/16 (2459)	9-0 13/16 (2764)	10-6 13/16 (3221)
<b>FS (mm)</b>	5-11 13/16 (1824)	7-5 13/16 (2281)	7-11 13/16 (2434)	8-11 13/16 (2738)	10-5 13/16 (3196)
<b>DLO (mm)</b>	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)					
	6016	7616	8016	9016	10616
	6020	7620	8020	9020	10620
	6026	7626	8026	9026	10626

1 FRAME 4 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	7-11 1/2 (2426)	9-11 1/2 (3035)	10-7 1/2 (3239)	11-11 1/2 (3645)	13-11 1/2 (4255)
<b>Wood MO (mm)</b>	8-2 1/8 (2492)	10-2 1/8 (3102)	10-10 1/8 (3305)	12-2 1/8 (3712)	14-2 1/8 (4321)
<b>RO (mm)</b>	8-0 (2438)	10-0 (3048)	10-8 (3251)	12-0 (3658)	14-0 (4267)
<b>FS (mm)</b>	7-11 (2413)	9-11 (3023)	10-7 (3226)	11-11 (3632)	13-11 (4242)
<b>DLO (mm)</b>	1-1 19/32 (345)	1-7 19/32 (498)	1-9 19/32 (548)	2-1 19/32 (650)	2-7 19/32 (802)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)					
	8016	10016	10816	12016	14016
	8020	10020	10820	12020	14020
	8026	10026	10826	12026	14026

Details and Elevations not to scale.

- Some transoms available factory mulled.
- For stand alone wood units in masonry openings add 1 1/16" (17) to the masonry opening height only.

Please consult your local Marvin representative for masonry openings that include casings and subsills.

For further details and drawings visit the 'Tools and Documents' section at Marvin.com.