

Retractable Screen Pull Handle

Field Applied Instruction



The Marvin Retractable Screen features an optional handle that can be field applied. The pull handle should be installed on the pull bar of the screen. ***This handle is not suitable for use on Ultimate Awning or Ultimate Replacement Awning.***

NOTE: Numbers listed in parentheses () are metric equivalents in millimeters rounded to the nearest whole number.

You Will Need to Supply

Awl Phillips screwdriver

Drill with a 7/64" (3) bit

Parts Included in Kit

1- Handle 2- #7 x 1/2"(12) screws

NOTE: Handle placement should be centered on pull bar, but not to exceed 10" (254) from center.

1. Center pull handle template on pull bar at the center of the pull bar. Mark the location of the screws with an awl.
2. Pre-drill the holes with a 7/64"(3) bit.

3. Use a Phillips screwdriver and supplied screws to secure the handle to the pull bar.

