STOP!



CRITICAL INSTALLATION STEPS

1. Do not unlock sash or remove shipping blocks located between sash and frame prior to securing the frame into the rough opening.

2. Take care to maintain an even reveal (spacing) between the perimeter of sash and frame during installation.

3. After installation, remove shipping blocks from perimeter of the frame.

