

# Marvin Lock Status Sensor Window Display Installation Instructions

1. The battery, charger, and panel are separately boxed. Charge battery fully before starting.
2. Connect male end to unit female end encased in wall. See [Figure 1](#).



Figure 1

3. Connect battery pack to panel connector. Turn battery pack "on". See [Figure 2](#).



Figure 2

4. Remove hook and loop fastener backing from plate. See [Figure 3](#).



Figure 3

5. Align and center plate on wall and stick plate to the wall. Ensure hook and loop fastener fully adheres. See [Figure 4](#).



Figure 4

6. Cycle unit prior to use. See [Figure 5](#).



Figure 5