

Marvin Lock Status Sensor Window Display Installation Instructions

1. The battery, charger, and panel are separately boxed. Charge battery fully before starting.
2. Connect male end to unit female end encased in wall. See Figure 1.



Figure 1

3. Connect battery pack to panel connector. Turn battery pack "on". See Figure 2.



Figure 2

4. Remove hook and loop fastener backing from plate. See Figure 3.



Figure 3

5. Align and center plate on wall and stick plate to the wall. Ensure hook and loop fastener fully adheres. See Figure 4.



Figure 4

6. Cycle unit prior to use. See Figure 5.



Figure 5