







# SLIDING FRENCH DOOR TRANSOMS




## 1 FRAME 1 SASH 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	2-7 15/16 (811)	3-1 15/16 (964)	4-1 15/16 (1268)	5-1 1/8 (1553)	6-1 1/8 (1857)	8-1 1/8 (2467)
<b>Wood MO (mm)</b>	2-10 9/16 (878)	3-4 9/16 (1030)	4-4 9/16 (1335)	5-3 3/4 (1619)	6-3 3/4 (1924)	8-3 3/4 (2534)
<b>RO (mm)</b>	2-8 7/16 (824)	3-2 7/16 (976)	4-2 7/16 (1281)	5-1 5/8 (1565)	6-1 5/8 (1870)	8-1 5/8 (2480)
<b>FS (mm)</b>	2-7 7/16 (799)	3-1 7/16 (951)	4-1 7/16 (1256)	5-0 5/8 (1540)	6-0 5/8 (1845)	8-0 5/8 (2454)
<b>DLO (mm)</b>	1-7 19/32 (498)	2-1 19/32 (650)	3-1 19/32 (955)	4-0 25/32 (1239)	5-0 25/32 (1544)	7-0 25/32 (2153)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)						
	2616	3016	4016	5016	6016	8016
	2620	3020	4020	5020	6020	8020
	2626	3026	4026	5026	6026	8026




## 1 FRAME 1 SASH WITH CENTER STILE 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	5-1 1/8 (1553)	6-1 1/8 (1857)	8-1 1/8 (2467)
<b>Wood MO (mm)</b>	5-3 3/4 (1619)	6-3 3/4 (1924)	8-3 3/4 (2534)
<b>RO (mm)</b>	5-1 5/8 (1565)	6-1 5/8 (1870)	8-1 5/8 (2480)
<b>FS (mm)</b>	5-0 5/8 (1540)	6-0 5/8 (1845)	8-0 5/8 (2454)
<b>DLO (mm)</b>	1-9 3/4 (552)	2-3 3/4 (705)	3-3 3/4 (1010)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)			
	5016	6016	8016
	5020	6020	8020
	5026	6026	8026




## 1 FRAME 2 SASH WITH CENTER STILE 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	7-9 1/4 (2369)	9-3 1/4 (2826)	12-3 1/4 (3740)
<b>Wood MO (mm)</b>	7-11 7/8 (2435)	9-5 7/8 (2892)	12-5 7/8 (3807)
<b>RO (mm)</b>	7-9 3/4 (2381)	9-3 3/4 (2838)	12-3 3/4 (3753)
<b>FS (mm)</b>	7-8 3/4 (2356)	9-2 3/4 (2813)	12-2 3/4 (3727)
<b>DLO (mm)</b>	1-9 3/4 (552)	2-3 3/4 (705)	3-3 3/4 (1010)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)			
	7616	9016	12016
	7620	9020	12020
	7626	9026	12026

## 1 FRAME 2 SASH WITH 2 CENTER STILE 1/6 HEIGHT (2/0 AND 2/6 HEIGHTS SEE BELOW)

<b>Clad MO (mm)</b>	9-11 1/2 (3035)	11-11 1/2 (3645)	15-11 1/2 (4864)
<b>Wood MO (mm)</b>	10-2 1/8 (3102)	12-2 1/8 (3712)	16-2 1/8 (4931)
<b>RO (mm)</b>	10-0 (3048)	12-0 (3658)	16-0 (4877)
<b>FS (mm)</b>	9-11 (3023)	11-11 (3632)	15-11 (4851)
<b>DLO (mm)</b>	1-9 3/4 (552)	2-3 3/4 (705)	3-3 3/4 (1010)

1-6 1/4 (464) 1-8 1/4 (514) 1-6 1/2 (470) 1-6 (457) 0-9 5/16 (237)			
	10016	12016	16016
	10020	12020	16020
	10026	12026	16026

2-0 and 2-6 Heights:		
	2-0 Height	2-6 Height
Clad MO (mm)	2-0 1/4 (616)	2-6 1/4 (768)
Wood MO (mm)	2-2 1/4 (667)	2-8 1/4 (819)
RO (mm)	2-0 1/2 (622)	2-6 1/2 (775)
FS (mm)	2-0 (610)	2-6 (762)
DLO (mm)	1-3 5/16 (389)	1-9 5/16 (541)

Details and Elevations not to scale.

- Some transoms available factory mullled.
- For stand alone wood units in masonry openings add 1/16" (17) to the masonry opening height only.

Please consult your local Marvin representative for information on structural mulling guidelines and masonry openings that include casings and subsills.

For further details and drawings visit the 'Tools and Documents' section at Marvin.com.

Ultimate Sliding French Door Transom: USFDTR  
 Ultimate Wood Sliding French Door Transom: UWSFDTR