

Non-Operable Lock Component Instructions—Essential

Double Hung, Glider, Glider Triple Sash and Single Hung



SAFETY INFORMATION



WARNING: Blocks Escape in Fire and Emergency

The Lock Limiter is not designed to be easily disengaged. The Lock Limiter cannot be readily removed in case of fire or emergency.

WARNING: No Window Rescue Above 75 ft. (6th floor)

Do not rely on being rescued from windows above 75 ft. (6th floor). Follow building fire escape plan.

WARNING: Not a Security Device

The Lock Limiter is not a security device. Do not rely on the Lock Limiter to secure your home.

ATTENTION: Builder/Installer: Leave a copy of this information in a conspicuous location, or in the Homeowner's Information packet, for the original owner/occupant.

YOU WILL NEED TO SUPPLY:

Phillips driver and T15 Torx driver

1. Open the lock to remove existing screw



2. Close the lock.



3. Install the lock limiter and tighten the screw (#6 x 1 1/4" Torx head).



4. Non-operable lock component installed. Install the warning label included with your kit on the window.



NOTE: The tamper resistant screw cannot be readily removed in case of fire or emergency.

NOTE: The tamper resistant screw is not designed to be easily disengaged.

19971062
2019-07-29

Non-Operable Lock Component Instructions—Essential

Double Hung, Glider, Glider Triple Sash and Single Hung



SAFETY INFORMATION



WARNING: Blocks Escape in Fire and Emergency

The Lock Limiter is not designed to be easily disengaged. The Lock Limiter cannot be readily removed in case of fire or emergency.

WARNING: No Window Rescue Above 75 ft. (6th floor)

Do not rely on being rescued from windows above 75 ft. (6th floor). Follow building fire escape plan.

WARNING: Not a Security Device

The Lock Limiter is not a security device. Do not rely on the Lock Limiter to secure your home.

ATTENTION: Builder/Installer: Leave a copy of this information in a conspicuous location, or in the Homeowner's Information packet, for the original owner/occupant.

YOU WILL NEED TO SUPPLY:

Phillips driver and T15 Torx driver

1. Open the lock to remove existing screw



2. Close the lock.



3. Install the lock limiter and tighten the screw (#6 x 1 1/4" Torx head).



4. Non-operable lock component installed. Install the warning label included with your kit on the window.



NOTE: The tamper resistant screw cannot be readily removed in case of fire or emergency.

NOTE: The tamper resistant screw is not designed to be easily disengaged.

19971062
2019-07-29